- to start kserver manually:
 - Execute on krunc as daq "start_kserver"

kbrowser

- browse histograms from kserver
- browse histograms from files (.hbook .root).
 Default directory is: /runcond/root/physmon/
- in overlap mode, display normalized